

## 1. General Description

This Document contains the log data of a read out logfile. It shows what happened with the specified vbar unit during the latest time

Version of PC Software	<b>5.3.4 29.10.2012</b>
Date	<b>Sat Dec 12 12:08:59 EET 2015</b>
Serial	<b>1520007484</b>
Prod Date	<b>19.6.2013 11:37</b>
Firmware	<b>5.3</b>
Patchlevel	<b>4</b>

## 2. Chronological List of Events

✔	0:10	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	0:20	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	0:30	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	0:40	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	0:50	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	1:00	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	0:00	Coldstart	A Coldstart is done on the beginning of each switch on time. A Coldstart can happen only, if the VBar Units is disconnected from power for more than 5 Seconds.
✔	0:00	Reset Reason: Power On	This happens if power is applied to the VBar unit. Usually this is ok, but it shall never happen in operational mode. So if a reset happens during flight, this points to a power problem. During flight the power on reset results in a warmstart. If a coldstart happens during flight, the power loss was more than 5 Seconds
▶	0:00	Bank 0 Loaded	Bank 0 was loaded from the non volatile memory. This can be triggered my manual backswitch from the userinterface as well as in flight if bank switch is programmed to the aux channel. On Startup the Bank 0 is loaded by default.
▶	0:05	Calibration Finished	At each Coldstart, the sensor and RC Values are calibrated to the actual seen values. If the calibration is finished, this message confirms the storage of data into the internal non volatile calibration memory
✔	0:15	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	0:25	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	0:35	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	0:45	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	0:55	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	1:05	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
⚠	1:06	The Cyclic Ring is active	If the agility of a Heli is set to the possibilities of the mechanic and aerodynamic limits, this did not happen. However in 3D Flying the agility cannot set high enough to fulfill the pilots needs. So this limiter is in action dependant on the flwon actions. If it is active very often, there is a potential problem with the mechanics. Using lighter blades will help increasing the natural agility preventing hitting the cyclic ring all the time.
✔	0:00	Coldstart	A Coldstart is done on the beginning of each switch on time. A Coldstart can happen only, if the VBar Units is disconnected from power for more than 5 Seconds.
✔	0:00	Reset Reason: Power On	This happens if power is applied to the VBar unit. Usually this is ok, but it shall never happen in operational mode. So if a reset happens during flight, this points to a power problem. During flight the power on reset results in a warmstart. If a coldstart happens during flight, the power loss was more than 5 Seconds
▶	0:00	Bank 0 Loaded	Bank 0 was loaded from the non volatile memory. This can be triggered my manual backswitch from the userinterface as well as in flight if bank switch is programmed to the aux channel. On Startup the Bank 0 is loaded by default.
⚠	0:01	Init Failed, retrying...	The Init process of the sensors is very sensitive to movements of the heli or from other external disturbances, i.e. Voltage jumps and glitches. This can lead to a failed initialization. In this Case it is repeated. If this repeats itself all the time, this can point to a defective sensors.
▶	0:06	Calibration Finished	At each Coldstart, the sensor and RC Values are calibrated to the actual seen values. If the calibration is finished, this message confirms the storage of data into the internal non volatile calibration memory
✔	0:16	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	0:26	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	0:36	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	0:46	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.

✔	0:56	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	1:06	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	1:16	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	1:26	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	1:36	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	1:46	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	1:56	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	2:06	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	2:16	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	2:26	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	2:36	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	2:46	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	2:56	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	3:06	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	3:16	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	0:00	Coldstart	A Coldstart is done on the beginning of each switch on time. A Coldstart can happen only, if the VBar Units is disconnected from power for more than 5 Seconds.
✔	0:00	Reset Reason: Power On	This happens if power is applied to the VBar unit. Usually this is ok, but it shall never happen in operational mode. So if a reset happens during flight, this points to a power problem. During flight the power on reset results in a warmstart. If a coldstart happens during flight, the power loss was more than 5 Seconds
▶	0:00	Bank 0 Loaded	Bank 0 was loaded from the non volatile memory. This can be triggered my manual backswitch from the userinterface as well as in flight if bank switch is programmed to the aux channel. On Startup the Bank 0 is loaded by default.
▶	0:07	Calibration Finished	At each Coldstart, the sensor and RC Values are calibrated to the actual seen values. If the calibration is finished, this message confirms the storage of data into the internal non volatile calibration memory
✔	0:17	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	0:27	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	0:37	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	0:47	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	0:57	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	1:07	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	1:17	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	1:27	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✘	1:37	Aileron Sensor Value out of Range	The Sensor delivers Values that are not trustful. Rotational rates, that will create this values are usually not possible in air. The Sensor may be defective. This can happen in certain cases if the heli is handled on ground, or on very hard landings or very extreme Vibrations.

✘	1:37	Elevator Sensor Value out of Range	The Sensor delivers Values that are not trustful. Rotational rates, that will create this values are usually not possible in air. The Sensor may be defective. This can happen in certain cases if the heli is handleed on ground, or on very hard landings or very extreme Vibrations.
⚠	1:38	The Cyclic Ring is active	If the agility of a Heli is set to the possibilities of the mechanic and aerodynamic limits, this did not happen. However in 3D Flying the agility cannot set high enough to fulfill the pilots needs. So this limiter is in action dependant on the flwon actions. If it is active very often, there is a potential problem with the mechanics. Using lighter blades will help increasing the natural agility preventing hitting the cyclic ring all the time.
✘	1:38	Aileron Sensor Value out of Range	The Sensor delivers Values that are not trustful. Rotational rates, that will create this values are usually not possible in air. The Sensor may be defective. This can happen in certain cases if the heli is handleed on ground, or on very hard landings or very extreme Vibrations.
▶	1:45	Raised Vibration Level	There was detected a raised level of Vibration. Since the vibration detector has to decide which signal is vibration and chis is the intended measurement signal, this can happen sometimes on hard 3d moves. It shall not happen all the time. If this error is reported repeditly very often, check the heli for vibration sources.
✔	1:55	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	2:05	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	2:15	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	2:25	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	2:35	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	2:45	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	0:00	Coldstart	A Coldstart is done on the beginning of each switch on time. A Coldstart can happen only, if the VBar Units is disconnected from power for more than 5 Seconds.
✔	0:00	Reset Reason: Power On	This happens if power is applied to the VBar unit. Usually this is ok, but it shall never happen in operational mode. So if a reset happens during flight, this points to a power problem. During flight the power on reset results in a warmstart. If a coldstart happens during flight, the power loss was more than 5 Seconds
▶	0:00	Bank 0 Loaded	Bank 0 was loaded from the non volatile memory. This can be triggered my manual backswitch from the userinterface as well as in flight if bank switch is programmed to the aux channel. On Startup the Bank 0 is loaded by default.
▶	0:05	Calibration Finished	At each Coldstart, the sensor and RC Values are calibrated to the actual seen values. If the calibration is finished, this message confirms the storage of data into the internal non volatile calibration memory
✔	0:15	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
⚠	0:17	The Cyclic Ring is active	If the agility of a Heli is set to the possibilities of the mechanic and aerodynamic limits, this did not happen. However in 3D Flying the agility cannot set high enough to fulfill the pilots needs. So this limiter is in action dependant on the flwon actions. If it is active very often, there is a potential problem with the mechanics. Using lighter blades will help increasing the natural agility preventing hitting the cyclic ring all the time.
⚠	0:18	The Cyclic Ring is active	If the agility of a Heli is set to the possibilities of the mechanic and aerodynamic limits, this did not happen. However in 3D Flying the agility cannot set high enough to fulfill the pilots needs. So this limiter is in action dependant on the flwon actions. If it is active very often, there is a potential problem with the mechanics. Using lighter blades will help increasing the natural agility preventing hitting the cyclic ring all the time.
✔	0:28	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	0:38	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	0:48	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	0:58	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	1:08	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	1:18	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	1:28	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	1:38	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	1:48	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.

✔	1:58	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	2:08	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	2:18	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	2:28	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.
✔	2:38	Good Health Message (10sec)	This Message describes the good health state. That means, that the VBar unit does not see any error or Info Message in the last 10 Seconds.